Vacuum valve HIVR

Maximum flow rate: 240L/min(ANR)

HANWHA



Product characteristics


- *Mechanical adjustable pressure reducing valve
- *Targeted supply of compressed air through precise pressure regulation
- *Used for detection and measurement, such as leak detection






Product structure

- *Top fixing piece (1)
- *Valve body fixing parts (2)
- *Subject (3)
- *Fixed nut (4)
- *G3/8 quick change pipe joint (5)



Product advantages

- *Mechanical adjustment has extremely high repeatability accuracy
- *The set value can maintain extremely high accuracy
- *Can be installed in any position





Vacuum valve **HIVR**

Maximum flow rate: 240L/min(ANR)



HANWHA



HIVR Ordering NO

HIVR	20		FG03
1	2	_	3

1-Series	2-Subject			3-Screw thread	
HIVR	Valve	20	Maximum flow rate240L/min(ANR)	F Internal thread	G03-G3/8


HIVR Technical Data

Models	Use fluid	Set pressure range ¹⁾ [kPa]	Pressure resistanc ²⁾ [kPa]	Air consumption [L/min]	Temperature [°C]	VAC [mm]	SET [mm]
IRV20	air	-100~-1.3	100	0.6(ANR)以下	5~60	ф6	ф6


1) Please note that this item may vary depending on the pressure of the vacuum pump.

2) In situations with pressure gauges, once positive pressure is input, the pressure gauge will be damaged. In the case of applying positive pressure, although the vacuum pressure regulating valve is not damaged, the main valve part inside the pressure regulating valve becomes "open", and positive pressure will be input into the vacuum pump, which may malfunction. When using a vacuum pressure regulating valve in the suction handling system, please

Refer to the following piping example and be careful not to introduce positive pressure into the vacuum pump. In addition, the vacuum valve cannot adjust the positive pressure.







Pressure characteristics (representative values)

Vacuum valve HIVR


Maximum flow rate: 240L/min(ANR)

HANWHA





HIVR Specification



Models	L	L1	D	D1	R	R1	н	G	G1
IRV20	53	40	2	38	3.30	26	79	M5	G3/8